



## **22240 ANTI-SKID GRIT**

**Directions for use:**

Apply one coat 22210, 22220, 22250, or 22254 and allow to dry for 15 minutes. Scatter 22240 Anti Skid Grit evenly over truck bed and tailgate. Let dry for 15 minutes before applying a second coat of Truck Bed Coating over top of scattered 22240. Allow to cure as per the instructions for Truck Bed Coating.

**Quantity needed:** For full size truck (8 foot bed) uses approximately 226g - 8 oz (1 box) or as needed to obtain desired texture.